**TrailerConnnect® Data Management Center**

With TrailerConnnect® Data Management Center, Schmitz Cargobull offers a tool for simple and secure data integration in one platform. Data can be transferred easily, in a controlled and secure manner to external platforms (e.g. transport management systems (TMS), fleet management systems (FMS)).

Instruction for using the Data Management Center (DMC)

1. Create an Export-Account

If you want to share the telematics data with a data recipient, please select DMC (1) and Export Accounts (2) and select the "Plus Icon" (3).


2. Name assignment for the export account

Give the export account a name (1) and select your data provider (2).

If necessary, you will be prompted to add further characteristics for the partner.
Add these after consulting with the data provider. (3)

By clicking on (4), you can define which data is to be transferred during a tour-related data push when Tour Track is activated in the standard system. The prerequisite for this is that tour planning has already been created under "Tour Track".

3. Selection of the data to be tourbased

Select the data to be shared by selecting the possible points and confirm your selection (1).

## 4. Confirm the account creation

Confirm the created export account (1).

## 5. Checking the information in the "Export endpoints" view

(1) The created export account is listed in the overview.
Click on "Export endpoints" (2) to access the export endpoint settings screen.

6. Creation of the export endpoint

Click on the "plus sign" (1) at "Export endpoint configuration" to create a new endpoint.

Add the name of the export endpoint (1) and select the export account (2).

Check the information and confirm the attachment by clicking on (1).

7. Configuration of the export endpoint

1. define whether you want to transfer trip data
2. define if you want to transfer Tapa data
3. select individual options for permanent data transfer

4. here you enter contacts who are to be contacted in the event of a malfunction in the data transfer.
5. here you set whether the data of the entire vehicle fleet or of individual vehicles / vehicle groups are to be transmitted
6. if data of single vehicles shall be transferred, the selection of vehicles is done via (6)
7. list display, if the data transmission of individual vehicles has been selected.

Steps for selecting individual vehicles

Storage of the selected vehicles